

# ETH Course 402-0248-00L: Electronics for Physicists II (Digital)


- **Taught by:** Tobi Delbruck, Alejandro Linares
- **Department:** ETH Zurich Department of Physics (D-PHYS)
- **Day/Time:** Weekly on Fridays from 1315 - 1700 in Picaardsaal, ETH Hoenggerberg Campus, [HPT](#) Room C103
- **Breaks:** No class in some weeks, check schedule on wiki.
- **Language:** English.
- **Credits:** 4 credit points.
- **Exam:** There is no exam but students must successfully complete the class exercises. Attendance sheet will be used.
- **Class wiki:** google “dig delbruck”

**[www.ini.uzh.ch/~tobi/wiki/doku.php?id=dig:start](http://www.ini.uzh.ch/~tobi/wiki/doku.php?id=dig:start)**




# Prerequisites

- **Companion course:**  
[Electronics for Physicists I \(Analog\)](#), Fall semester, taught by Roland Horisberger.
- The digital course complements the analog course by teaching how to build systems that convert and process analog information.
- You should have had some programming experience, preferably with C. Students (or at least each group of 2-3 students) need a laptop computer, Windows or Linux (but only Windows supported by Tobi). Mac OS can use VM.

# 1<sup>st</sup> half: Embedded systems with microcontrollers



# 2<sup>nd</sup> half: Logic design with FPGA



PCB SMD assembly

PCB design and layout


# Embedded system design example

## Ada's luminous tactile floor




# Ada's luminous tactile floor






# Neon Tile



# Part of floor's "Interbus" network





# Tile PCB

To Dim Box

Power supply

Interbus

uController


ADC

Interbus

Diagnostics

EEPROM program

6K




# PCB assembly



+




=



X 500 @ 25 CHF/board

# Tile Microcontroller Program

## Interrupt service routines (ISRs)



1000 lines C/ assembler code running on 8052 derivative  
Two demo tiles have been running continuously for >5 years!

# The ATmega168P / 328P


- AT = Atmel: Big microcontroller company
- mega: microcontroller family
- 16: 16KB Flash memory / 32: 32KB Flash
- 8: 8-bit architecture
- P: PicoPower Technology. Optional. For low power battery-based applications.

# ATmega16/328P capabilities

- **System Functions**
  - Power and Clock Manager
  - Low Freq Internal Oscillator
  - Watchdog Timer
  - Real-Time Clock Timer
- **Interrupt Controller**
  - Fixed priority. One level of interruption. Interruptions with flag (can remember) or without. Global Interrupt Enable (I-bit) is disabled during an interrupt service.
- **NO Universal Serial Bus (USB)**
  - This micro hasn't USB. The nano board provide an USB-USART interface from FTDI company.
- One 16-bit **Timer/Counter (TC)** with Auto-Reload and PWM
- Two 8-bit **Timer / Counter (TC)** with AR and PWM
- One 8-channel 10-bit **Analog-To-Digital Converter (ADC)**, 76.9ks/s
- SPI, USART, I2C


# Clocks


Figure 28-1. Maximum Frequency vs.  $V_{CC}$



Arduino ATmega328P uses a 16MHz Resonator with 5v Vcc, to keep compatibility to ATmega8

# ATmega328 simplified block diagram








# Atmega168/328P datasheet

- 440 pages
- Useful for architecture comprehension
- Peripheral descriptions
- Not all details are necessary since Arduino bootloader make things easier!!

# Arduino Sketch



```
Blink | Arduino 1.0.5  
Blink §  
/*  
  Blink  
  Turns on an LED on for one second, then off for one second, repeatedly.  
  
  This example code is in the public domain.  
  */  
  
// Pin 13 has an LED connected on most Arduino boards.  
// give it a name:  
int led = 13;  
  
// the setup routine runs once when you press reset:  
void setup() {  
  // initialize the digital pin as an output.  
  pinMode(led, OUTPUT);  
}  
  
// the loop routine runs over and over again forever:  
void loop() {  
  digitalWrite(led, HIGH); // turn the LED on (HIGH is the voltage level)  
  delay(100);              // wait for a second  
  digitalWrite(led, LOW);  // turn the LED off by making the voltage LOW  
  delay(500);              // wait for a second  
}
```

Done uploading.

Binary sketch size: 1,084 bytes (of a 30,720 byte maximum)  
Binary sketch size: 1,084 bytes (of a 30,720 byte maximum)

10 Arduino Nano w/ ATmega328 on /dev/tty.usbserial-A9615VNN

# C programming for Arduino

## ANSI C STYLE

```
void setup(void);  
void loop(void);  
  
void main(void) {  
    setup(); //perform one-time initializations  
    while(1) {  
        loop(); //repeat this over and over  
    }  
}  
  
void setup(void) {  
}  
void loop(void) {  
}
```

## ARDUINO CODE STYLE

```
void setup() {  
}  
  
void loop() {  
}
```

Any other necessary stuff is included by Arduino IDE during compilation time and it is transparent for the user / programmer (you)

- Managing a LED:
  - Setup: `pinMode(13, OUTPUT); // bitSet(DDRB,5);`
  - Loop: `digitalWrite(13, HIGH); //or LOW`
- Managing Serial port:
  - Setup: `Serial.begin(rate); //Serial.end();`
  - Loop: `Serial.println(data);`  
`Serial.println(data, data_type); //DEC,BIN,HEX,OCT, BYTE`  
`Serial.print(data, data_type);`  
`n=Serial.available(); //n=number of bytes (max 128B)`  
`b=Serial.read(); // Serial.write(b);`  
`b=Serial.peek();`  
`Serial.flush()`
  - `void serialEvent() {}`

# Standard AVR code

```
#include <stdio.h>
#include <avr/io.h>

#ifndef F_CPU
#   error Must define F_CPU or pass it as compiler argument
#endif

FILE uart_out = FDEV_SETUP_STREAM(uart_putChar, NULL, _FDEV_SETUP_WRITE);
void main(void) __attribute__((noreturn));

void uart_init(){
#   define BAUD 9600
#   include <util/setbaud.h>
    UBRRH0H = UBRRH_VALUE;
    UBRRL0L = UBRRL_VALUE;
#   if USE_2x
        USCR0A |= _BV(U2X);
#   else
        USCR0A &= ~_BV(U2X);
#   endif
    UCSR0B |= _BV(TXEN);           // enable transmit
}

int uart_putChar(char c, FILE *unused){
    if (c == '\n')                // a line feed character also
        uart_putChar('\r', unused); // requires a carriage return
    loop_until_bit_is_set(UCSR0A, UDRE0); // wait for UDR0 to be ready
    UDR0 = c;                      // write character
    return 0;                      // return
}


void main(void){
    uart_init();
    fprintf(&uart_out, "Hello, UART!\n");
    stdout = &uart_out;           // set up stdout
    printf("UART demo...\n");
    for (uint8_t i = 0; i < 10; i++)
        printf("Number %i ", i);
    while(1);
}
```

# Arduino Serial code

```
int led = 13;

// the setup routine runs once when you press reset:
void setup() {
  // initialize the digital pin as an output.
  pinMode(led, OUTPUT);
  Serial.begin(9600);
}


// the loop routine runs over and over again forever:
void loop() {
  digitalWrite(led, HIGH); // turn the LED on (HIGH is the voltage level)
  delay(1000);             // wait for a second
  Serial.println("Hello UART");
  digitalWrite(led, LOW); // turn the LED off by making the voltage LOW
  delay(1000);            // wait for a second
}
```




FTDI

Resistors Arrays

Regulator



# Arduino Nano EFP2 RTC/INI schematics





# Exercise 1

- Installing and running Arduino tools.
- Opening and understanding basic blinking Example Sketch and run it.
- Add Serial communication to Serial Monitor for “debugging” your Sketch.
- Arranging time for soldering your own Arduino Nano board and make it compatible with Sketch.
- Exercise 2: probably debugging and repairing your own Arduino Nano board


# The AVR32 AT32UC3B1256

- AT = Atmel: Big microcontroller company
- 32 = 32 bit architecture
- UC3 = Atmel microcontroller family
- B = more powerful and expensive variant (\$7 each @25 units)
- 1 = revision
- 256 = 256kB internal high speed flash memory (32kB single cycle SRAM)


# AVR32 capabilities


- **System Functions**
  - Power and Clock Manager
  - Two Multipurpose Oscillators
  - Watchdog Timer
  - Real-Time Clock Timer
- **Interrupt Controller**
  - Auto-vectored Low Latency Interrupt Service with Programmable Priority
- **Universal Serial Bus (USB)**
  - Device 2.0 Full Speed (12Mbps~1Mbps)
- **One Three-Channel 16-bit Timer/Counter (TC)**
- **One 7-Channel 20-bit Pulse Width Modulation Controller (PWM)**
- **One 8-channel 10-bit Analog-To-Digital Converter (ADC), 384ks/s**
- plus many more modules

# The “bronze” board





# AT32UC3B1256 "copper" board schematic





# AVR32








# AVR32 datasheet – ~700 pages

- Intro/Core features: 200pp
- Peripherals: 400pp (e.g. USB 180pp, GPIO 19pp)
- Electrical characteristics: 20pp

# AVR32 Analog to Digital converter


- 10-bit Successive approximation register (SAR) type
- 6 multiplexed single-ended input channels
- Max combined sample rate 384ks/s
- External trigger
- Hardware sequencer
- Peripheral DMA



# Audio stereo bitstream DAC

The Audio Bitstream DAC converts a 16-bit sample value to a digital bitstream with an average value proportional to the sample value

- **Oversampled D/A conversion architecture**
  - Oversampling ratio fixed 128x
  - FIR equalization filter
  - Digital interpolation filter: Comb4
  - 3rd Order Sigma-Delta D/A converters
- **Digital bitstream outputs**
- **Parallel interface**
- **Connected to DMA Controller for background transfer without CPU intervention**



# AVR32 Studio

- Eclipse IDE
- gcc 'tool chain'
- Integrated DFU

AVR - usb-rgb-ldr/src/main.c - AVR32 Studio

File Edit Source Refactor Navigate Search Project Run Framework Window Help

Project Explorer

- usb-rgb-ldr
  - Software Libraries
  - Binaries
  - Includes
  - boot
  - Debug
  - src
    - SOFTWARE\_FRAMEW
    - conf\_usb.h
    - device\_task.h
    - enum\_example.c
    - main.c
    - usb\_descriptors.c
    - usb\_descriptors.h
    - usb\_specific\_request.c
    - usb\_specific\_request.h

main.c

```
// RGG LED main.c
////////////////////////////////////////////////////
////////////////////////////////////////////////////

#include "compiler.h"
#include "preprocessor.h"
#include "pm.h"
#include "gpio.h"
#include "pwm.h"

// #include "print_funcs.h"
#include "intc.h"
#include "power.h"
#include "conf_usb.h"
#include "usb_descriptors.h"

#if USB_DEVICE
#include "usb_descriptors.c"
#include "usb_descriptors.h"
#include "usb_specific_request.c"
#include "usb_specific_request.h"
#endif

// clock setup
////////////////////////////////////////////////////
#define FOSC0 12000000 // 12MHz frequency
```

Building Workspace

Building all...

Always run in background

Run in Background Cancel Details >>

Problems Properties Console

C-Build [usb-rgb-ldr]

```
-I../src/SOFTWARE_FRAMEWORK/DRIVERS/GPIO -I../src/SOFTWARE_FRAMEWORK/DRIVERS/FLASHC
-I../src/SOFTWARE_FRAMEWORK/UTILS/PREPROCESSOR -I../src/SOFTWARE_FRAMEWORK/UTILS
-I../src/SOFTWARE_FRAMEWORK/DRIVERS/ADC -Wa,-g3
-osrc\SOFTWARE_FRAMEWORK\DRIVERS\INTC\exception.o
..src\SOFTWARE_FRAMEWORK\DRIVERS\INTC\exception.x
avr32-gcc -I../src -I../src/SOFTWARE_FRAMEWORK/DRIVERS/INTC
-I../src/SOFTWARE_FRAMEWORK/DRIVERS/USBB/ENUM/DEVICE
-I../src/SOFTWARE_FRAMEWORK/DRIVERS/USBB/ENUM/HOST
-I../src/SOFTWARE_FRAMEWORK/DRIVERS/USBB/ENUM -I../src/SOFTWARE_FRAMEWORK/DRIVERS/USBB
-I../src/SOFTWARE_FRAMEWORK/DRIVERS/PWM -I../src/SOFTWARE_FRAMEWORK/DRIVERS/PM
-I../src/SOFTWARE_FRAMEWORK/DRIVERS/GPIO -I../src/SOFTWARE_FRAMEWORK/DRIVERS/FLASHC
-I../src/SOFTWARE_FRAMEWORK/UTILS/PREPROCESSOR -I../src/SOFTWARE_FRAMEWORK/UTILS
-I../src/SOFTWARE_FRAMEWORK/DRIVERS/ADC -I../src/SOFTWARE_FRAMEWORK/SERVICES/USB -O0 -g3
-Wall -c -fmessage-length=0 -mpart=uc3b1256 -ffunction-sections -masm-addr-pseudos
-osrc\SOFTWARE_FRAMEWORK\DRIVERS\INTC\intc.o ..src\SOFTWARE_FRAMEWORK\DRIVERS\INTC\intc.c
```

Outline


```
# cG
# cB
# R_PWM_PIN
# R_PWM_FUNCTION
# R_PWM_CHANNEL_ID
# G_PWM_PIN
# G_PWM_FUNCTION
# G_PWM_CHANNEL_ID
# B_PWM_PIN
# B_PWM_FUNCTION
# B_PWM_CHANNEL_ID
# pwm_opt : pwm_opt_t
# pwm_channel : avr32_pwm_channel_t[]
# channel_id : unsigned int[]
# TTT
# init_pwm() : void
# set_rgb(U8, U8, U8) : void
# ADC_CHANNEL
# ADC_PIN
# ADC_FUNCTION
# init_adc() : void
# get_adc_value() : U16
# sof_cnt : U32
# in_data_length : U8
# in_buf : U8[]
# out_data_length : U8
# out_buf : U8[]
# device_task_init(void) : void
# device_task(void) : void
# usb_sof_action(void) : void
# main() : int
```

AVR Targets

Name	Adapter	Board
AVR32 Simulat...	AVR32 Simulat...	AVR32
DFU	USB DFU	Unspec

Writable Smart Insert 20:17 Building Workspace: (35%)

# AVR32 Software Framework



# Exercise 1

- Installing and running AVR32 tools.
- Importing Daniel's usb-rgb-ldr\* example project.
- Installing libusb USB driver and 'copper' board.
- Programming sample copper board with usb-rgb-ldr.
- Installing python and pyusb.
- Running usb-rgb-ldr on copper board with LDR and RGB LEDs added.
- Arranging time for soldering your own copper or 'bronze' board.
- Exercise 2: probably debugging and repairing your own copper board, adding RGB LED and LDR


\* LDR=Light dependent resistor, RGB LED=Red/Green/Blue Light Emitting Diode

# Surface mount soldering exercise






# Finding INI=Inst. of Neuroinformatics




Irchel




# USB silicon retina




Camera PCB acquires asynchronous digital data from retina chip, time stamps it, sends data over high speed USB interface to PC. It also receives control commands for biasing, etc. from PC and sends to retina chip serially.







Digital interface connector



Silicon retina



CPLD logic  
Handshaking state machine  
Time-stamping  
Multicamera synchronization



High speed USB microcontroller  
(Cypress FX2) with parallel FIFO  
Interface to CPLD

