

# ETH Course 402-0248-00L: Electronics for Physicists II (Digital)


- **Taught by:** Tobi Delbruck, Alejandro Linares
- **Department:** ETH Zurich Department of Physics (D-PHYS)
- **Day/Time:** Weekly on Fridays from 1315 - 1700 in Picaardsaal, ETH Hoenggerberg Campus, [HPT](#) Room C103
- **Breaks:** No class in some weeks, check schedule on wiki.
- **Language:** English.
- **Credits:** 4 credit points.
- **Exam:** There is no exam but students must successfully complete the class exercises. Attendance sheet will be used.
- **Class wiki:** google “dig delbruck”

**[www.ini.uzh.ch/~tobi/wiki/doku.php?id=dig:start](http://www.ini.uzh.ch/~tobi/wiki/doku.php?id=dig:start)**



# Prerequisites

- **Companion course:**  
[Electronics for Physicists I \(Analog\)](#), Fall semester, taught by Roland Horisberger.
- The digital course complements the analog course by teaching how to build systems that convert and process analog information.
- You should have had some programming experience, preferably with C. Students (or at least each group of 2-3 students) need a laptop computer, Windows or Linux (but only Windows supported by Tobi). Mac OS can use VM.


# 1<sup>st</sup> half: Embedded systems with microcontrollers




# 2<sup>nd</sup> half: Logic design with FPGA



PCB SMD assembly



PCB design and layout



# Embedded system design example


## Ada's luminous tactile floor






# Ada's luminous tactile floor






# Neon Tile





# Part of floor's "Interbus" network





# Tile PCB

To Dim Box

Power supply

Interbus

uController


ADC

Interbus

Diagnostics

EEPROM program

6K






# PCB assembly



+




||



X 500 @ 25 CHF/board

# Tile Microcontroller Program

## Interrupt service routines (ISRs)



1000 lines C/assembly code running on 8052 derivative  
Two demo tiles have been running continuously for >5 years!

# The ATmega168P / 328P

- AT = Atmel: Big microcontroller company
- mega: microcontroller family
- 16: 16KB Flash memory / 32: 32KB Flash
- 8: 8-bit architecture
- P: PicoPower Technology. Optional. For low power battery-based applications.




# ATmega16/328P capabilities

- **System Functions**
  - Power and Clock Manager
  - Low Freq Internal Oscillator
  - Watchdog Timer
  - Real-Time Clock Timer
- **Interrupt Controller**
  - Fixed priority. One level of interruption. Interruptions with flag (can remember) or without. Global Interrupt Enable (I-bit) is disabled during an interrupt service.
- **NO Universal Serial Bus (USB)**
  - This micro hasn't USB. The nano board provide an USB-USART interface from FTDI company.
- One 16-bit **Timer/Counter (TC)** with Auto-Reload and PWM
- Two 8-bit **Timer / Counter (TC)** with AR and PWM
- One 8-channel 10-bit **Analog-To-Digital Converter (ADC)**, 76.9ks/s
- SPI, USART, I2C


# Clocks


Figure 28-1. Maximum Frequency vs.  $V_{CC}$



Arduino ATmega328P uses a 16MHz Resonator with 5v  $V_{CC}$ , to keep compatibility to ATmega8

# ATmega328 simplified block diagram







# Atmega168/328P datasheet

- 440 pages
- Useful for architecture comprehension
- Peripheral descriptions
- Not all details are necessary since Arduino bootloader make things easier!!

# Arduino Sketch

```
/*
  Blink
  Turns on an LED on for one second, then off for one second, repeatedly.

  This example code is in the public domain.
  */

// Pin 13 has an LED connected on most Arduino boards.
// give it a name:
int led = 13;

// the setup routine runs once when you press reset:
void setup() {
  // initialize the digital pin as an output.
  pinMode(led, OUTPUT);
}

// the loop routine runs over and over again forever:
void loop() {
  digitalWrite(led, HIGH); // turn the LED on (HIGH is the voltage level)
  delay(100);              // wait for a second
  digitalWrite(led, LOW);  // turn the LED off by making the voltage LOW
  delay(500);              // wait for a second
}
```

Done uploading.

Binary sketch size: 1,084 bytes (of a 30,720 byte maximum)  
Binary sketch size: 1,084 bytes (of a 30,720 byte maximum)

10 Arduino Nano w/ ATmega328 on /dev/tty.usbserial-A9615VNN

# C programming for Arduino

## ANSI C STYLE

```
void setup(void);  
void loop(void);  
  
void main(void) {  
    setup(); //perform one-time initializations  
    while(1) {  
        loop(); //repeat this over and over  
    }  
}  
  
void setup(void) {  
}  
void loop(void) {  
}
```

## ARDUINO CODE STYLE

```
void setup() {  
}  
  
void loop() {  
}
```

Any other necessary stuff is included by Arduino IDE during compilation time and it is transparent for the user / programmer (you)

- Managing a LED:
  - Setup: `pinMode(13, OUTPUT); // bitSet(DDRB,5);`
  - Loop: `digitalWrite(13, HIGH); //or LOW`
- Managing Serial port:
  - Setup: `Serial.begin(rate); //Serial.end();`
  - Loop: `Serial.println(data);`  
`Serial.println(data, data_type); //DEC,BIN,HEX,OCT, BYTE`  
`Serial.print(data, data_type);`  
`n=Serial.available(); //n=number of bytes (max 128B)`  
`b=Serial.read(); // Serial.write(b);`  
`b=Serial.peek();`  
`Serial.flush()`
  - `void serialEvent() {}`



# Standard AVR code

```
#include <stdio.h>
#include <avr/io.h>

#ifndef F_CPU
#   error Must define F_CPU or pass it as compiler argument
#endif

FILE uart_out = FDEV_SETUP_STREAM(uart_putchar, NULL, _FDEV_SETUP_WRITE);
void main(void) __attribute__((noreturn));

void uart_init(){
#   define BAUD 9600
#   include <util/setbaud.h>
    UBRRH0H = UBRRH_VALUE;
    UBRRH0L = UBRRL_VALUE;
#   if USE_2x
        USCR0A |= _BV(U2X);
#   else
        USCR0A &= ~_BV(U2X);
#   endif
    USCR0B |= _BV(TXEN);           // enable transmit
}

int uart_putchar(char c, FILE *unused){
    if (c == '\n')                 // a line feed character also
        uart_putchar('\r', unused); // requires a carriage return
    loop_until_bit_is_set(USCR0A, UDRE0); // wait for UDR0 to be ready
    UDR0 = c;                       // write character
    return 0;                       // return
}

void main(void){
    uart_init();
    fprintf(&uart_out, "Hello, UART!\n");
    stdout = &uart_out;           // set up stdout
    printf("UART demo...\n");
    for (uint8_t i = 0; i < 10; i++)
        printf("Number %i ", i);
    while(1);
}
```

# Arduino Serial code


```
int led = 13;

// the setup routine runs once when you press reset:
void setup() {
  // initialize the digital pin as an output.
  pinMode(led, OUTPUT);
  Serial.begin(9600);
}

// the loop routine runs over and over again forever:
void loop() {
  digitalWrite(led, HIGH); // turn the LED on (HIGH is the voltage level)
  delay(1000);             // wait for a second
  Serial.println("Hello UART");
  digitalWrite(led, LOW); // turn the LED off by making the voltage LOW
  delay(1000);            // wait for a second
}
```



# Arduino Nano EFP2 RTC/INI schematics



# Exercise 1

- Installing and running Arduino tools.
- Opening and understanding basic blinking Example Sketch and run it.
- Add Serial communication to Serial Monitor for “debugging” your Sketch.
- Arranging time for soldering your own Arduino Nano board and make it compatible with Sketch.
- Exercise 2: probably debugging and repairing your own Arduino Nano board



# Surface mount soldering exercise





# Finding INI=Inst. of Neuroinformatics

